

DJ Mischpult

Pioneer DJM-600		CHF	60.00
Pioneer DJM-800		CHF	100.00
Pioneer DJM-900NXS2		CHF	120.00
Ecler Smac40		CHF	50.00

CD Player

Pioneer CDJ-200	MP3		CHF	40.00
Pioneer CDJ-900	MP3	USB Input	CHF	90.00
Pioneer DJM-1000MK3	MP3		CHF	60.00
Pioneer DJM-2000NXS2	MP3	USB Input	CHF	120.00
Pioneer DDJ-SB2 Serato DJ Intro	MP3	USB Typ B	CHF	50.00
Stage Line CD304DJ	Klappcase	Dual-CD-Player	CHF	40.00
DiscoTec CD-1600	Klappcase	Dual-CD-Player	CHF	40.00